

XC-HR90 NEW

- Non-TV Output**
- Progressive Scan**
- 1/3 Type CCD**
- Square Pixels**
- C Lens Mount**
- SXGA Output**
- Partial Scan**
- HD/VD External Sync**
- 30/15 FPS Selectable**
- Mode 1 (Non-Rest Mode) External Trigger Shutter**
- Mode 2 (Non-Rest Mode) External Trigger Shutter**
- Restart Reset**
- Long Exposure**
- RS232C Control**



Connection Diagram **P70**



Outline

The XC-HR90 is an analog interface camera with high-speed, high-quality picture output of approximately 1.25 megapixels (SXGA) at a standard frame rate of 30 fps, with a compact size that makes it ideal for use in combination with industrial equipment. Other features include a partial scan function that enables faster image read-out, and settings that can be made via the rear panel or remotely via RS-232C serial interface.

Features


- 1/3 type high-resolution progressive scan CCD monochrome camera module
- Full pixel read-out, SXGA size (Effective lines: 1280 (H) x 960 (V))
Image output: 30 fps, 15 fps (selectable)
- Vertical frequency
49.302 MHz (30 fps)
24.651 MHz (15 fps)
- Analog output
- Partial scan function
- Binning function
- External control possible (RS-232C)

Accessories

- Compact camera adaptor
 - DC-700/700CE
- 12-pin camera cable (CE standard)
 - CCXC-12P02N (2 m)
 - CCXC-12P05N (5 m)
 - CCXC-12P10N (10 m)
 - CCXC-12P25N (25 m)
- Tripod adaptor
 - VCT-551

Dimensions


Camera body of all XC-HR models



*1: for 3-M3 screw
*2: for 4-M2 screw
Unit: mm


Spectral Sensitivity Characteristics

●XC-HR90 (Typical Values)



(Lens characteristics and light source characteristics excluded.)

Location and Function of Parts and Controls




① Lens mount (C-mount)

Attach any C-mount lens or optical equipment suitable for high-resolution images (SXGA-compatible).

Note

Be sure that the lens does not project more than 10 mm from the lens mount.



② Reference holes (top)

③ Reference holes/ tripod screw holes (bottom)


These precision screw holes are for locking the camera module. Using these holes to lock the camera module secures the optical axis alignment.

The reference screw holes can also be used as tripod adaptor screw holes. To install on a tripod, attach the VCT-551 tripod adaptor using these four screw holes.

Specifications

XC-HR90	
Image device	1/3 type progressive scan IT CCD
Effective picture elements	1,296 (H) x 966 (V)
Effective lines	1,280 (H) x 960 (V)
Image size	SXGA
Unit cell size	3.75 μm (H) x 3.75 μm (V)
Lens mount	C mount
Sync system	Internal/External (auto)
External sync signal input/output	HD/VD (HD/VD level: 2.5 to 5 Vp-p, 75 W)
External sync allowable frequency	±1 % (in horizontal synchronous frequency)
Jitter	Less than 20 ns
Scanning system	Non-interlace Progressive scan
Output signal frequency	Binning: 2-line combined / Normal: 1-line sequential output
Video output	1.0 Vp-p, sync negative, 75 Ω, unbalanced
CCD vertical drive frequency	30fps: 29.7kHz (Normal mode) 26.79kHz (Binning mode) 15fps: 14.85kHz (Normal mode) 14.85kHz (Binning mode)
CCD horizontal drive frequency	30fps: 30Hz (Normal mode) 54.1Hz (Binning mode) 15fps: 15Hz (Normal mode) 30Hz (Binning mode)
Horizontal resolution	960 TV lines
Sensitivity	400 lx F5.6 (γ=OFF, FIX GAIN (0 dB))
Minimum illumination	1 lx (F1.4, g=OFF, GAIN +18 dB)
S/N ratio	56 dB (0 dB GAIN)
Gain	Manual (0 to +18dB)/FIX (0dB) (adjustable on rear panel or via RS-232C)
Gamma	OFF (fixed)
White clip	820 mV ±70 mV (F1.8, FIX GAIN (0 dB))
Shutter	Normal shutter, Restart/Reset, External trigger shutter (Mode 1/Mode 2)
Normal shutter speed	1/100, 1/125, 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/10000, 1/25000, 1/50000, 1/100000 s
External trigger shutter speed	DIP switch settings: 1/100, 1/125, 1/250, 1/500, 1/1,000, 1/2,000, 1/4,000, 1/10,000, 1/25,000, 1/50,000, 1/100,000 s Trigger pulse width settings: 1/4 to 1/50,000 s
External trigger	Polarity: +, Width: 2 ms to 250 ms, Input impedance: 10k Ω or more (H: +2.5 to 5.0 V, L: 0 to +0.6 V)
Partial scanning	Readout of center 480 lines at 56 fps, Readout of center 240 lines at 95.8 fps (settable using DIP switches) Readout of 60 effective lines selectable from 16 vertical divisions at max. 204.8 fps (settable via RS-232C)
Power requirements	DC 12 V (+10.5 V to +15.0 V)
Power consumption	approx. 2.8 W
Dimensions	29 (W) x 29 (H) x 63.5 (D) mm (not including protruding parts)
Mass	80g
Operating temperature	-5 to 45 °C
Storage temperature	-30 to 60 °C
Performance guarantee temperature	0 to 40 °C
Operating humidity	20 to 80%
Storage humidity	20 to 95%
Vibration resistance	10 G (20 Hz to 200 Hz) 20 minutes for each direction - x,y,z
Shock resistance	70G
MTBF	73,880 hrs. (approx. 8.4 years)
Regulation	UL60065, FCC Class A Digital Device, CE (EN61326/97ClassA+A1/98+A2/01+A3/03), ICE S-003 Class AS (EN55022/94 ClassA+AI/95+A2/97), VCCI ClassA
Supplied accessories	Lens mount cap (1), Operating instructions (1)

Rear Panel




Note

Be sure to turn the power off before making switch settings. As the variable controller for manual adjustment is a small precise component, do not apply force more than required when adjusting. Doing so will break the component. The controller is not a 360-degree rotation type. Do not turn the controller beyond the stopper of the component. The range of rotation is about 230 degrees. For the adjustment of the variable controller, use a flathead screwdriver. The sizes of a recommended flathead screwdrivers are 1.9mm width, 0.5mm thickness and more than 0.45mm length.

- ① **VIDEO OUT/DC IN/SYNC (video output/DC power/sync signal)connector (12-pin connector)**
Connect a CCXC-12P05N camera cable to this connector to obtain power from the +12V DC power supply and also to enable video signal output from the camera module. When a sync signal generator is connected to this connector, the camera module is synchronized with the external sync signals (HD/VD signals).
 - ② **M Gain (Manual Gain) control knob**
If you have selected MANUAL (manual adjustment) with DIP switch 4, this knob adjusts the gain.
 - ③ **Shutter speed/Mode setting DIP switch**
 - ① **Shutter speed (bits 1-4)**
Set an appropriate shutter speed (factory setting: OFF).
 - ② **Partial scan mode switch (5)**
The factory setting of this switch is partial scan OFF.
 - ③ **Restart reset/External trigger shutter mode switch (bits 6 to 8)**
By inputting an external restart/reset signal, you can capture the information of single screens at arbitrary timing. By inputting an external trigger signal, you can capture imaging information on fast-moving objects at a precise moment in time. The factory settings for these switches are for normal operation (restart/reset and external trigger shutter OFF).
 - ④ **Gain switch (bit 9)**
This switch selects FIX (fixed) or MANUAL (manual adjustment) (factory setting: FIX (left side)).
 - ⑤ **Binning mode switch (bit 0)**
Switches the video signal output mode between binning OFF and binning ON (factory setting: OFF).
 - ④ **Mode setting DIP switch**
 - ⑥ **75Ω termination switch**
Turn this to OFF (switch down position) when not terminating the external sync signal. The factory setting of this switch is ON (switch up position).
 - ⑦ **HD/VD signal input/output switch**
Set the switch to the down position (INT) to output HD/VD signals from the camera module, and set it to the up position (EXT) to input HD/VD signals from an external unit. The factory setting for this switch is the up position (EXT).
- Note**
Even when the switch is in the up position (EXT), the camera operates in internal synchronization mode unless an external HD signal is input. In this case, however, the camera module will not output internal sync signals.
- ⑧ **30 fps/15 fps switch**
30 fps: switch down position
15 fps: switch up position
 - ⑨ **RS-232C ON/OFF switch**
ON : switch up position
OFF: switch down position


Factory Mode Settings of Rear Panel



No.	Switch	Factory setting mode
1	M GAIN control knob	— *
2	Shutter speed and mode setting DIP switches	All OFF (left)
3	Mode setting DIP switches	
	① 75 termination switch	ON (switch up position)
	② HD/VD signal input/output switch`	HD/VD signal input (switch up position)
	③ 30 fps/15 fps switch	30 fps (switch down position)
	④ RS-232C ON/OFF switch	OFF (switch down position)

* This unit is shipped from the factory with the gain switch (DIP switch 9) being set to "FIX," so the M GAIN control knob is not operative unless the switch setting is changed. When the gain switch (DIP switch 9) is set to MANUAL, you can rotate this knob to adjust gain over the range 0 to 18 dB.

Connector Pin Assignments



Pin No.	Camera sync output	External mode (HD/VD)	Restart/Reset	External trigger shutter
1	Ground	Ground	Ground	Ground
2	+12V DC	+12V DC	+12V DC	+12V DC
3	Video output (Ground)	Video output (Ground)	Video output 1 (Ground)	Video output (Ground)
4	Video output (Signal)	Video output (Signal)	Video output 1 (Signal)	Video output (Signal)
5	HD output (Ground)	HD input (Ground)	HD input (Ground)	HD input (Ground)
6	HD output (Signal)	HD input (Signal)	HD input (Signal)	HD input (Signal)
7	VD output (Signal)	VD input (Signal)	Reset (Signal)	VD input (Signal)
8	(RS232C (Rx)) *1	(RS232C (Rx)) *1	(RS232C (Rx)) *1	(RS232C (Rx)) *1
9	(RS232C (Tx)) *1	(RS232C (Tx)) *1	(RS232C (Tx)) *1	(RS232C (Tx)) *1
10	—	—	—	WEN output (Signal)
11	—	—	—	Trigger pulse input (Signal)
12	VD output (Ground)	VD input (Ground)	Reset (Ground)	VD input (Ground) *2

*1 When communicating with RS232C. *2 Common ground for pins 7, 10, 11.

About the Camera Control Method

This camera can be controlled via a host device (such as a personal computer). The table below shows the functions that can be controlled. The camera can be controlled by sending commands that correspond to the control items, with parameters for the desired settings, if necessary, from the host device.

Control function	Description
Operating mode	Normal/ Restart reset/ Trigger mode 1/ Trigger mode 2
Shutter speed	Normal
	30 fps mode: OFF (1/30) to 1/1,000,000
	15 fps mode: OFF (1/15) to 1/5000
Trigger	Internal setting: OFF (same as above) to 1/100,000
	Setting by trigger pulse width
Gain	0 to +18 dB
Binning function	OFF/ON
Partial scan function	OFF/ON: Area settings can be made for 16 zones
HD/VD signal input/output	External sync signal input/Internal sync signal output
75 termination	ON/OFF
Frame rate	30 fps/15 fps

Make sure to supply power to the camera module and confirm that the camera module is operating before inputting an external sync or trigger signal. Inputting an external signal before supplying the power may cause the camera module to malfunction.
Note: When using the external sync in combination with control from a host device (such as a personal computer), make sure the frequency is within the specified range. The camera cannot be controlled when the input is outside the specified frequency range.

About the Electronic Shutter

There are two shutter types: normal shutter and external trigger shutter. Select them with the DIP switches on the rear panel.

Normal Shutter

This mode provides continuous video output with the electronic shutter selected by switches to capture a high-speed moving object clearly.

Normal Shutter	Other modes*
8 <input type="checkbox"/>	8 <input type="checkbox"/>

* "Other modes" refers to restart/reset mode and external trigger shutter mode.

Normal shutter speed settings

30fps

1/125	1/250	1/500	1/1000	OFF	OFF
1 <input type="checkbox"/>					
2 <input type="checkbox"/>					
3 <input type="checkbox"/>					
4 <input type="checkbox"/>					
1/2000	1/4000	1/10000	1/20000	OFF	OFF
1 <input type="checkbox"/>					
2 <input type="checkbox"/>					
3 <input type="checkbox"/>					
4 <input type="checkbox"/>					
1/50000	1/100000	1/100		OFF	
1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>		1 <input type="checkbox"/>	
2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>		2 <input type="checkbox"/>	
3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>		3 <input type="checkbox"/>	
4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>		4 <input type="checkbox"/>	

The shutter will be off when the DIP switch is set as below.

15fps

1/125	1/250	1/500	1/1000	OFF	OFF
1 <input type="checkbox"/>					
2 <input type="checkbox"/>					
3 <input type="checkbox"/>					
4 <input type="checkbox"/>					
1/2000	1/4000	1/10000	1/25000	OFF	OFF
1 <input type="checkbox"/>					
2 <input type="checkbox"/>					
3 <input type="checkbox"/>					
4 <input type="checkbox"/>					
1/50000	1/100			OFF	OFF
1 <input type="checkbox"/>	1 <input type="checkbox"/>			1 <input type="checkbox"/>	
2 <input type="checkbox"/>	2 <input type="checkbox"/>			2 <input type="checkbox"/>	
3 <input type="checkbox"/>	3 <input type="checkbox"/>			3 <input type="checkbox"/>	
4 <input type="checkbox"/>	4 <input type="checkbox"/>			4 <input type="checkbox"/>	

The shutter will be off when the DIP switch is set as below.

(Unit: seconds)

External Trigger Shutter

Inputting an external trigger pulse enables the camera to capture fast-moving objects clearly with precise timing.

Set DIP switches 6, 7, and 8 on the rear panel to Mode 1 or Mode 2. When you set the trigger pulse width to 1/3 of a second or more, the output signal changes to the normal VIDEO signal.

Mode 1	Mode 2
6 <input type="checkbox"/>	6 <input type="checkbox"/>
7 <input type="checkbox"/>	7 <input type="checkbox"/>
8 <input type="checkbox"/>	8 <input type="checkbox"/>

Note

High-rate scan mode cannot be used while in external trigger shutter mode 2.

There are two modes for the timing in which video signals are obtained.

Mode 1 (Non-reset mode)

In this mode, a video signal synchronized with a VD signal is output after a trigger pulse is input.

- The video signal is synchronized with the external VD signal when an external HD*/VD signal is input.
- The video signal is synchronized with an internal VD signal when no external HD*/VD signal is input.

* External or internal synchronization is selected automatically depending on the presence or absence of external HD input.

Mode 2 (Reset mode)

In this mode, an internal VD is reset, then a video signal is output a certain period of time after trigger pulse input.

To Set the External Trigger Shutter


There are two ways to set the shutter speed.

Using trigger pulse width

Set all DIP switches (1 to 4 on the rear panel) to OFF.

You can obtain an arbitrary shutter speed by setting the trigger pulse width to the range of 2 μsec to 250 msec.

Exposure time = Trigger pulse width + 5 μsec



Note

An incorrect video signal will be output if you input a new trigger pulse before the video signal output for the previous trigger pulse is output completely.

Using the DIP switches on the rear panel

For shutter speeds, see the following table.

Mode 1 (Non-reset mode)/Mode 2 (Reset mode)

1/125	1/250	1/500	1/1000
1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>
2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>
3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>
4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>
1/2000	1/4000	1/10000	1/25000
1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>
2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>
3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>
4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>
1/50000	1/100000	1/100	
1 <input type="checkbox"/>	1 <input type="checkbox"/>	1 <input type="checkbox"/>	
2 <input type="checkbox"/>	2 <input type="checkbox"/>	2 <input type="checkbox"/>	
3 <input type="checkbox"/>	3 <input type="checkbox"/>	3 <input type="checkbox"/>	
4 <input type="checkbox"/>	4 <input type="checkbox"/>	4 <input type="checkbox"/>	


(Unit: seconds)

Restart/Reset

To Set Restart/Reset Mode

The information on one screen can be extracted at any time by externally inputting restart/reset signals (HD/VD). To enter this mode, set the trigger shutter switches (6 to 8) on the rear panel of the camera as shown in the figure below.

To use restart/reset mode and Partial scan mode simultaneously, set the Partial scan mode switch (5) to ON (right side).



Long Exposure

The Restart/Reset function extends the CCD accumulation time, resulting in highly sensitive image capture. This function is effective when you cannot gain satisfactory sensitivity under normal operating conditions, or when you want to observe the trail of a moving object. Extend the VD interval (T) between external VD pulses.

